



LIANJIE

ACRE
SURVEYING SOLUTIONS

LJ-JGCM-I

Switch Rail Lateral Wear Gauge



High Measuring Accuracy

LCD Digital display

Metric /Imperial unit

• Introduction:

The Switch Rail Lateral Wear is used to measure the switch rail lateral wear and the descent height value of the switch rail, this device can be used for all types of switch rail.

LCD Digital display, Switch between metric and imperial unit at will, that help easy to read.



Package



Equipped with a simple calibrator, it could be used for quick calibration before use.



Main Technical Parameter:

Model	LJ-JGCM-1
Type	1.Vertical Ruler:Digital 2.Lateral Ruler: Digital
Measure range	1.Vertical Ruler:92-195mm 2.Lateral Ruler: 0-120mm
Resolution	Digital ruler:0.01mm
Calibration block	Optional

info@grupoacre.com

<http://www.grupoacre.com>

ACRE
SURVEYING SOLUTIONS